



Predefined MIDI Map

Version: MADRIX 5.4.



Denon DJ MC7000



Please note: Deck 1 and Deck 2 must be activated!

[1] Filter Color Red Deck A	[39] Filter Color Red Deck B	[75] Filter Color Red Main Output
[2] Filter Color Green Deck A	[40] Filter Color Green Deck B	[76] Filter Color Green Main Output
[3] Filter Color Blue Deck A	[41] Filter Color Blue Deck B	[77] Filter Color Blue Main Output
[4] Filter Deck A	[42] Filter Deck B	[78] Filter Color White Main Output
[PUSH 4] Filter Reset Deck A	[PUSH 42] Filter Reset Deck B	[79] Filter Main Output
[5] Filter Color Mode Deck A 'Allow Through'	[43] Filter Color Mode Deck B 'Allow Through'	[80] Blackout
[6] Filter Color Mode Deck A 'Filter Out'	[44] Filter Color Mode Deck B 'Filter Out'	[81] Master Value
[7] Filter Color Mode Deck A 'Colorize'	[45] Filter Color Mode Deck B 'Colorize'	[82] Audio Output Mute
[8] Not used	[46] Not used	[83] Audio Output Value
[9] Submaster Deck A	[47] Submaster Deck B	[84] Audio Input Mute
[10] Storage Place Deck A UP DOWN	[48] Storage Place Deck B UP DOWN	[85] Audio Input Value
[10 PUSH] Storage ID Deck A UP DOWN	[48 PUSH] Storage ID Deck B UP DOWN	[86] Main Output Strobe Color Red
[11] Layer Opacity Current Layer Deck A	[49] Layer Opacity Current Layer Deck B	[87] Main Output Strobe Color Green

[12] Speedmaster Deck A	[50] Speedmaster Deck B	[88] Main Output Strobe Color Blue
[13] Frame ID Deck A	[51] Frame ID Deck B	[89] Main Output Strobe White Blue
[14] Speed Pitch Storage Place Deck A DOWN	[52] Speed Pitch Storage Place Deck B DOWN	[90] Main Output Strobe Mode
[15] Speed Pitch Storage Place Deck A UP	[53] Speed Pitch Storage Place Deck B UP	[91] Main Output Strobe ON
[16] Speedmaster Pause TOGGLE Deck A	[54] Speedmaster Pause TOGGLE Deck B	[92] Main Output Strobe Value
[17] Storage Place Parameter Chaser Step Previous Deck A	[55] Storage Place Parameter Chaser Step Previous Deck B	[93] Fade Time 1/10 Sec
[18] Storage Place Parameter Chaser Step Next Deck A	[56] Storage Place Parameter Chaser Step Next Deck B	[94] Crossfader
[19] Storage Place Parameter Chaser Play/Pause TOGGLE Deck A	[57] Storage Place Parameter Chaser Play/Pause TOGGLE Deck A	[95] Fade Type
[20] Crossfader Fade To Left	[58] Crossfader Fade To Right	
[21] Blind Current Layer Deck A	[59] Blind Current Layer Deck B	
[22] Solo Current Layer Deck A	[60] Solo Current Layer Deck B	
[23] Layer ID Deck A DOWN	[61] Layer ID Deck B DOWN	
[24] Layer ID Deck A UP	[62] Layer ID Deck B UP	
[25 Activated] + [29] - [36] Storage Place Deck A 1 - 8	[63 Activated] + [67] - [74] Storage Place Deck B 1 - 8	
[26 Activated] + [29] - [36] Storage Place Deck A 9 - 16	[64 Activated] + [67] - [74] Storage Place Deck B 9 - 16	
[27 Activated] + [29] - [36] Storage Place Deck A 17 - 24	[65 Activated] + [67] - [74] Storage Place Deck B 17 - 24	
[28 Activated] + [29] - [36] Storage Place Deck A 25 - 32	[66 Activated] + [67] - [74] Storage Place Deck B 25 - 32	
[37] Cue List Back		
[38] Cue List Go		