



Predefined MIDI Map

Version: MADRIX 5.4.



Denon DJ MC4000



[1] Filter Color Red Deck A	[29] Filter Color Red Deck B	[57] Filter Color Red Main Output
[2] Filter Color Green Deck A	[30] Filter Color Green Deck B	[58] Filter Color Green Main Output
[3] Filter Color Blue Deck A	[31] Filter Color Blue Deck B	[59] Filter Color Blue Main Output
[4] Filter Deck A	[32] Filter Deck B	[60] Filter Main Output
[PUSH 4] Filter Reset Deck A	[PUSH 32] Filter Reset Deck B	[61] Blackout
[5] Submaster Deck A	[33] Submaster Deck B	[62] Master Value
[6] Solo Deck A Layer 1	[34] Solo Deck B Layer 1	[63] Activate Deck A
[7] Solo Deck A Layer 2	[35] Solo Deck B Layer 2	[64] Activate Deck B
[8] Solo Deck A Layer 3	[36] Solo Deck B Layer 3	[65] Storage Place UP DOWN Deck A if [63] is activated
[9] Solo Deck A Layer 4	[37] Solo Deck B Layer 4	[PUSH 65] Storage UP DOWN Deck A if [63] is activated
[10] Blind Deck A Layer 1	[38] Blind Deck B Layer 1	[65] Storage Place UP DOWN Deck B if [64] is activated
[11] Blind Deck A Layer 2	[39] Blind Deck B Layer 2	[PUSH 65] Storage UP DOWN Deck B if [64] is activated
[12] Blind Deck A Layer 3	[40] Blind Deck B Layer 3	[66] Main Output Strobe

[13] Blind Deck A Layer 4	[41] Blind Deck B Layer 4	[67] Main Output Strobe
[14] Speedmaster Deck A	[42] Speedmaster Deck B	[68] Fade Type 'XF'
[15] Speedmaster Deck A PAUSE	[43] Speedmaster Deck B PAUSE	[69] Fade Type 'WF'
[16] Frame ID Deck A if [17] is activated	[44] Frame ID Deck B if [45] is activated	[70] Fade Type 'BF'
[18] Not used	[46] Not used	[71] Fade Type 'Wipe X'
[19] Speed Pitch Storage Place Deck A DOWN	[47] Speed Pitch Storage Place Deck A DOWN	[72] Fade Time 1/10 Sec
[20] Speed Pitch Storage Place Deck A UP	[48] Speed Pitch Storage Place Deck A UP	[73] Crossfader
[21] Storage Place Deck A 1	[49] Storage Place Deck B 1	[74] Main Output Strobe Color Red
[22] Storage Place Deck A 2	[50] Storage Place Deck B 2	[75] Main Output Strobe Color Green
[23] Storage Place Deck A 3	[51] Storage Place Deck B 3	[76] Main Output Strobe Color Blue
[24] Storage Place Deck A 4	[52] Storage Place Deck B 4	[77] Main Output Strobe Color Value
[25] Storage Place Deck A 5	[53] Storage Place Deck B 5	[78] Audio Input Mute
[26] Storage Place Deck A 6	[54] Storage Place Deck B 6	[79] Audio Input Value
[27] Storage Place Deck A 7	[55] Storage Place Deck B 7	
[28] Storage Place Deck A 8	[56] Storage Place Deck B 8	