



Predefined MIDI Map

Version: MADRIX 5.4.



Numark Mixtrack Platinum



Please note: Pad Mode Manual Loop must be activated!

[1] Speed Pitch Storage Place Deck A DOWN	[24] Filter Deck B	[47] Filter Color Red Main Output
[2] Speed Pitch Storage Place Deck A UP	[25] Submaster Deck B	[48] Filter Color Green Main Output
[3] Submaster Deck A	[26 + 29 ACTIVATED] Filter Color Red Deck B	[49] Filter Color Blue Main Output
[4 + 6 ACTIVATED] Filter Color Red Deck A	[26 + 30 ACTIVATED] Filter Color Green Deck B	[50] Filter Color White Main Output
[4 + 7 ACTIVATED] Filter Color Green Deck A	[26 + 31 ACTIVATED] Filter Color Blue Deck B	[51] Blackout
[4 + 8 ACTIVATED] Filter Color Blue Deck A	[26 + 32 ACTIVATED] Filter Color White Deck B	[52] Master Value
[4 + 9 ACTIVATED] Filter Color White Deck A	[27] Speed Pitch Storage Place Deck B DOWN	[53] Activate Deck A
[5] Filter Deck A	[28] Speed Pitch Storage Place Deck B UP	[54] Activate Deck B
[10] Speedmaster Deck A	[34 + 33 ACTIVATED] Frame ID Deck B	[55] Storage Place UP DOWN Deck A if [53] is activated
[11 + 12 ACTIVATED] Frame ID Deck A	[34] Speedmaster Deck B	[55] Storage Place UP DOWN Deck B if [54] is activated
[13] Effect Parameter Chaser Deck A Play/Pause Layer 1	[36] Effect Parameter Chaser Deck B Play/Pause Layer 1	[Push 55] Storage UP DOWN Deck A if [53] is activated

[14] Effect Parameter Chaser Deck A Play/Pause Layer 2	[37] Effect Parameter Chaser Deck B Play/Pause Layer 2	[Push 55] Storage UP DOWN Deck B if [54] is activated
[15] Effect Parameter Chaser Deck A Play/Pause Layer 3	[38] Effect Parameter Chaser Deck B Play/Pause Layer 3	[56] Main Output Strobe Activate + Value
[16] Effect Parameter Chaser Deck A Play/Pause Layer 4	[39] Effect Parameter Chaser Deck B Play/Pause Layer 4	[57] Fade Type
[17] Effect Parameter Chaser Deck A Play/Pause Layer 5	[40] Effect Parameter Chaser Deck B Play/Pause Layer 5	[58] Fade Time 1/10 Sec
[18] Effect Parameter Chaser Deck A Play/Pause Layer 6	[41] Effect Parameter Chaser Deck B Play/Pause Layer 6	[59] Main Output Strobe Color Red
[19] Effect Parameter Chaser Deck A Play/Pause Layer 7	[42] Effect Parameter Chaser Deck B Play/Pause Layer 7	[60] Main Output Strobe Color Green
[20] Effect Parameter Chaser Deck A Play/Pause Layer 8	[43] Effect Parameter Chaser Deck A Play/Pause Layer 8	[61] Main Output Strobe Color Blue
[21] Cue List View TOGGLE	[44] Cue List View TOGGLE	[62] Main Output Strobe Color White
[22] Cue Storage Place Deck A	[45] Cue Storage Place Deck B	[63] Audio Input Mute
[23] Cue List Play/Pause TOGGLE	[46] Cue List Play/Pause TOGGLE	[64] Audio Input Value
		[65] Crossfader
		[66] Output Freeze