




## Predefined MIDI Map

Version: MADRIX 5.4.



## Behringer BCD3000

Also known as BCD 3000 / BCD-3000.



[1] No MIDI function	[13] FREE	[25] Layer Mix Mode UP
[2] FREE	[14] FREE	[26] Layer Mix Mode DOWN
[3] No MIDI function	[15] No MIDI function	[27] Crossfader Skip to Left/Skip To Right
[4] Cue List Open/Close	[16] FREE	[28] Master / Audio Input Level
[5] Color RED for Color Filter or Color-	[17] Crossfader Automatic Fade	[29] Audio Input Mute/Unmute / Cue

<b>fade</b> (see [11] and [12])		<b>List Play/Pause</b>
<b>[6] Color GREEN for Color Filter or Color-fade</b> (see [11] and [12])	<b>[18] No MIDI function</b>	<b>[30] Cue Storage Place</b>
<b>[7] Color BLUE for Color Filter or Color-fade</b> (see [11] and [12])	<b>[19] POWER LED / NO MIDI function</b>	<b>[31] Layer UP/DOWN</b>
<b>[8] Color WHITE for Color Filter or Color-fade</b> (see [11] and [12])	<b>[20] Crossfader</b>	<b>[32] Speed Master</b>
<b>[9] Crossfader Fade Type DOWN</b>	<b>[21] Crossfader Fade Time</b>	<b>[33] Storage Place UP/ DOWN</b>
<b>[10] Crossfader Fade Type UP</b>	<b>[22 Low Knob] Storage ID S1 – S128</b>	<b>[34] + [35] Storage Place Submaster</b>
<b>[11] Mode: Color Filter (Default)</b>	<b>[23] Cue List Go/Back</b>	<b>[34] + [35] Layer Submaster</b>
<b>[12] Mode: Color-Fade</b>	<b>[24] Cue List Play/Pause</b>	<b>[34] + [35] Layer Opacity</b>